

SUCTION PIPE

1. GENERAL

- This instruction applies to PVDF and polypropylene suction pipes.

2. SETUP

- Screw the (white) compression tubing fitting provided into the ½ inch NPT female thread at the top of the suction pipe.



- Insert your tubing into the compression tubing fitting and tighten by hand. (never more than ¼ turn past hand tight)
- If you ordered a check valve, it is already installed and the pipe should be tagged accordingly. If you are retrofitting a check valve, please see [separate instructions](#) that come with the check valve.



- Screw the suction pipe threaded mount into your container.
- Adjust the depth using the thumbscrew so the pipe is touching the bottom of the vessel. (don't worry about pressing it flat on the bottom, it will still draw liquid because the bottom will not be perfectly flat).

3. MAINTENANCE

- There is a screen located in the bottom of the pipe which can be removed with a coin.
- There is no regular maintenance required except replacing the check valve. (if applicable)



POLYPROPYLENE



KYNAR VERSION