

# RESIN MIXER

## 1. POWER

- Plug in AC adapter. (12VDC).



## 2. INSERT MIXING CUP

- Fill a disposable cup with the contents to be mixed and put it in the (yellow) “base cup”.
- Insert disposable wooden stick in alligator clip.



## 3. START MIXING

- Turn speed control knob to desired speed. (Power light comes on)
- If air bubble avoidance is a concern, keep mixing speed slow enough so mixture does not incorporate bubbles.
- For very low volumes, the mixer can be tilted so liquid collects around the mixing stick. 20ml is the smallest practical volume.



## 4. SPARE PARTS

- For replacement cups and sticks, see website for up-to-date sources.

Mar 25, 2020