

RESIN MIXER RM-1000

This instruction covers the setup and use of the resin mixer RM-1000.

1. POWER

- The unit is fully assembled and only needs power plugged in to start working.

2. MOUNT CONTAINER

- The blue plate has rubber grippers that squeeze together to hold your mixing container securely. (known as a Longworth chuck) There is a thumbscrew on the plate that will lock the plates in case you want extra security.

3. TURN ON ROTATION

- Turn on the speed knob to desired speed.

4. ADJUST STIR STICK

- Adjust the angle of the mixing stick using the black thumbscrews mounted on the steel rods. Try to get the stick so it scrapes the sides and bottom of the container.

5. OTHER POINTS

- There is no maintenance required. In case of disaster, Gizmo does sell spare chucks.

