



T2 TIMER INSTRUCTIONS

1. SET DESIRED TIME

- Choose minutes or seconds using blue jumper. (jumper on the pins is minutes, off the pins is seconds.
- Adjust rotary knobs to desired time: left knob represents tens, right knob the single minutes. Time is adjustable from 0-99 seconds or 0-99 minutes.



THREE SECONDS



THREE MINUTES

2. CHOOSE MODE

The timer is capable of 4 modes according to the following chart.

1. MANUAL SHUTOFF				
	1	2	3	4
	BTZ	CTS 2		
	MODE			
	BUTTON PUSH			
	LIGHT	TIME 1		
	BUZZER			
	RELAY			

2. AUTO SHUTOFF				
	1	2	3	4
	BTZ	CTS 2		
	MODE			
	BUTTON PUSH			
	LIGHT	TIME 1		
	BUZZER		2 sec	
	RELAY			

3. RELAY CLOSED DURING BOTH TIMES				
	1	2	3	4
	BTZ	CTS 2		
	MODE			
	BUTTON PUSH			
	LIGHT	TIME 1		TIME 2
	BUZZER		1sec	1sec
	RELAY			

4. RELAY OPEN DURING TIME 2 ONLY				
	1	2	3	4
	BTZ	CTS 2		
	MODE			
	BUTTON PUSH			
	LIGHT	TIME 1		TIME 2
	BUZZER			1s
	RELAY			

3. OPERATION

- Push the button to start the timing cycle.
- The LED will chirp once and then flash once per second to let you know it is timing.
- When time1 has elapsed, the buzzer sounds and the LED changes to a slow blink. Push the button again to silence the buzzer. If in mode 2, the timer will stop alarming by itself.
- Timing cycle can be cancelled by pushing the button during the cycle. Timer will chirp to let you know it has been cancelled.

Jun 21, 2023