

BLANK CUSTOMER INSTRUCTION

This instruction details how to install and use the resin mixer RM-150. The 150 refers to the maximum volume the cup can hold.

1. CUP

- Insert a cup into the cup holder. There is enough friction to keep the mixing cup from turning.



2. INSERT STICK

- Clamp a wood tongue depressor stick into the alligator clip.

3. MIX

- Turn on the speed knob to the correct speed. LED illuminates when mixing.



4. OTHER POINTS

- Its good practice to pour your resin you intend to use out of the cup and use only that portion. You can't count on the resin stuck to the cup being fully mixed.
- Some resins take a long time to cure. It is possible to advance the cure by blowing warm air into the cup.